

# CRL Spig-Lite Advanced

## Adjustable Glass Balustrade System

CRL Spig-Lite Advanced is our latest adjustable glass balustrade system that uses individual spigots and a proven adjustment system. It is quick and easy to install, raising the glass to 22 mm above the floor level which provides natural drainage.

It has been tested to BS6180:2011 to achieve 0.74kN loading required for residential and small commercial applications.

TESTED TO  
BS 6180:2011

For information call **FREE** on **00 800 0421 6144**  
Our technical advisers can help you!

e: [CRL@crlaurence.co.uk](mailto:CRL@crlaurence.co.uk) f: [00 800 0262 3299](tel:0080002623299) w: [crlaurence.co.uk](http://crlaurence.co.uk)

**CRL**<sup>®</sup>  
A CRH COMPANY

# CRL Spig-Lite Advanced is ideal for residential balustrade installations.

## ONLY 2 SPIGOTS & FIXINGS REQUIRED PER METRE

Extremely quick to install, elongated holes to allow for easy alignment.

## NO NEED TO DRILL THE GLASS

Our glass clamping mechanism removes the need to hold the glass with locking pins.

## NO DRAINAGE ISSUES

Free drainage between the spigots means no water gets trapped inside the balcony area.

## USES A PROVEN ADJUSTMENT SYSTEM

Horizontal alignment of each glass panel, ensuring the top edge of the glass is equal.

## QUALITY ENGINEERING

Tested to BS6180:2011 - 0.74kN for private residential and small commercial applications.

## GLASS THICKNESSES

- 12 mm and 15 mm toughened monolithic glass
- 17.52 and 21.52 mm toughened laminated glass

NOTE: ALL GLASS CLAMPS HAVE A 1MM TOLERANCE TO ACCEPT VARYING INTERLAYER THICKNESS



NOW AVAILABLE WITH END CAPS



## Spig-Lite Advanced is so easy to install

### STEP 1

Bolt the spigots to the substrate.  
(Only 2 spigots required per metre).

### STEP 2

Firmly squeeze the clamps around the glass and lower into the Spigots.

### STEP 3

Place the cap screw through the clamp bar and loosely screw on the rectangular nut. The bar needs to be spun so that the angled side of the bar is nearest the glass. To adjust the glass use a 5 mm Hex Key to tighten the screws to 6Nm.

### STEP 4

Slip the gasket in the top recess of the top bead. Apply neutral cure silicone to the top bead and end cap and fix in position.

NOW WITH EASIER INSTALLATION

For information call **FREE on 00 800 0421 6144**  
Our technical advisers can help you!

e: [CRL@crlaurence.co.uk](mailto:CRL@crlaurence.co.uk) f: [00 800 0262 3299](tel:0080002623299) w: [crlaurence.co.uk](http://crlaurence.co.uk)

**CRL**<sup>®</sup>  
A CRH COMPANY