



PROCEDURES:

- 11 INSTALL FLOATING HEADER ① ONTO GLASS CLAMPS ⑤ ⑥.
- 12 SECURE WITH TRUSS HEAD SCREWS ④. IF MINOR ADJUSTMENT OF CLAMPS IS REQUIRED, ACCESS TO THE HEX BOLTS ⑧ IS AVAILABLE FROM BELOW.