


FLOATING HEADER INSTALLATION INSTRUCTIONS



PROCEDURES:

- 13 CHECK THAT SETTING BLOCKS ARE INSTALLED IN HEADER.
- 14 INSTALL TRANSOM GLASS INTO HEADER. SECURE WITH GLAZING GASKET 13 INSIDE AND OUT.

CML FLOATING HEADER SYSTEM

C.R. Laurence Architectural Products
Phone Orders (800) 421-6144
Fax Orders (800) 262-3299
www.crlaurence.com

No	DESCRIPTION	QTY
1	FLOATING HEADER ASSEMBLY	1
2	CLOSER COVER PLATE	1
3	HEADER COVER PLATE	1
4	TRUSS HEAD SCREWS	8
5	OUTSIDE CLAMP BLOCK	2
6	INSIDE CLAMP BLOCK	2
7	GLASS GROMMET	4
8	HEX HEAD SCREW	4
9	CLOSER END PLATE	1
10	SOCKET HEAD SCREW	2
11	FIBER GASKET	1
12	END CAP	4
13	GLAZING GASKET	2